




# TAN AIR PNEUMATICS

## EPVF3000/5000 VALVE MANIFOLD ORDERING GUIDE&DIMENSIONS

TO: ORDER FOR EPVF3000 VALVE  
EPVV5F30-N° of Stations




( ): 3 position

L: Dimensions(mm), n: Stations

L \ n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	83.5	111	138.5	166	193.5	221	248.5	276	303.5	331	358.5	386	413.5	441	468.5	496	523.5	551	578.5
L <sub>2</sub>	71.5	99	126.5	152	181.5	209	236.5	264	291.5	319	346.5	374	401.5	429	456.5	484	511.5	539	566.5

TO: ORDER FOR EPVF5000 VALVE  
EPVV5F50-N° of Stations



L: Dimensions(mm), n: Stations

L \ n	2	3	4	5	6	7	8	9	10
L <sub>1</sub>	93	126	159	192	225	258	291	324	357
L <sub>2</sub>	80	118	146	179	212	245	278	311	344